

Installing an Attic Tent to seal Knee wall door!



Knee wall door



Attic Tent Vertically installed

Steps to install Attic Tent over knee wall door:

Align Attic Tent vertical to the back side of the door frame.

- 1. Insure that the zipper end is down.**
- 2. Fold flange under zipper side to attach to the floor.**
- 3. Staple around door frame on attic side and seal with a bead of caulk.**